






## Dust is abundant in the solar system


















### Student Dust Counter (SDC) operating in the outer solar system



#### Depolarization dust detector







Dust *mass* obtained from signal amplitude using the calibration relation

 $N_e = 5.63 \times 10^{17} m[g]^{1.3} v[km/s]^{3.0}$ 




## The LADEE mission and LDEX


**LADEE** = Lunar Atmosphere and **D**ust Environment Explorer

**LDEX** = **L**unar **D**ust **EX**periment (LDEX)

Operation: 2013-2014


Orbit: ~50x200 km elliptical orbit, 100 days of operation









## Instruments currently in development





NDA/DANTE



SUDA
Selected for flight
(approx. 2022)

Hyperdust
Proposed for
asteroid missions
(with DTS)

NDA/DANTE
Proposed for inner solar system dust investigations


**ENIJA**Proposed for
Enceladus mission


## Common theme: Compositional analysis

Instrument concepts developed at: LASP/University of Colorado and MPI-K/Heidelberg (now University of Stuttgart)




## In-situ detection/analysis principle - Impact Ionization





Measureable parameters:


- Velocity
- Mass
- Ion composition






### CDA made important science contributions to the Cassini mission








CDA on Cassini M/dM ~ 20-30




- Pronounced signatures of sodium and potassium salts in a water matrix
- NaCl, KCl, NaHCO3 are identified.
- Important implications for subsurface water reservoir (Postberg et al., Nature 2009)



# Hyperdust improvement over CDA



From M/dM ~ 30 (CDA)
To
M/dM ~ 200 (IDEX)






# Key Hyperdust requirements/features

Requirement	Justification
Effective target area: ≥ 600 cm <sup>2</sup>	To detect a statistically significant number of interplanetary and/or interstellar particles (interstellar dust flux on the order of 10 <sup>-5</sup> m <sup>-2</sup> s <sup>-1</sup> )
Mass resolution m/dm ≥ 200	To analyze the elemental/chemical/isotopic composition of ISDs
Dual polarity	To extend the chemical analysis capabilities by measuring both cation/anion TOF spectra (optional)
Ion detector dynamic range ≥ 10 <sup>6</sup>	To measure the TOF mass spectrum over a wide impact velocity and mass ranges
Dust charge sensitivity ≤ 150 e <sup>-</sup> rms noise	To measure the velocity vector of interstellar particles (submicron in size)
Low mass	Large size instrument requires composite structure




# Hyperdust functionality





### Hyperdust ion optics is optimized through numerical simulations



- Incoming dust particle
  - Size: ~1 μm
  - Speed: 1 70 km/s
- Energy goes to
  - Deforming target material
  - Heating
  - Breaking chemical bonds
  - Ionization

Time of flight of ions:


$$t(r_i, m) = b(r_i)\sqrt{m}$$

Mass resolution:

$$\frac{m}{\Delta m} = \frac{t}{2\Delta t}$$




## Hyperdust mechanical design






# Hyperdust mechanical design – cont.






## High dynamic range ion detector

- Custom made focused mesh electron multipliers
- Modeled after the MM1 detector (Johnston Tech), CDA heritage
- Existing functional TRL 6 prototype







Detector tapped at different stages provides high dynamic range



# ASIC CSA development for DTS

- ASIC = Application Specific Integrated Circuit
- CSA = Charge Sensitive Amplifier
- 64 parallel channels
- Charge on 1 micron radius dust at 5 V surface potential: 3500 electrons
- < 150 e<sup>-</sup> rms noise requirements (10 kHz 10 MHz bandwidth)
- Older tested ASIC performs with < 250 e<sup>-</sup> rms noise
- New ASIC with 0.18 micron technology designed to 150 e<sup>-</sup> rms noise
- New ASIC currently in fabrication (done by Nov 2016)











### Enabled science – variation with impact velocity

Impact velocity	Science capability
> 1.0 km/s	Impact detection – characterization of ejecta distribution (mass, density, dynamics)
> 1.5 km/s	Identification of basic compositional types (e.g., ice, rocky, metallic, organic)
> 3.0 km/s	Basic compositional analysis – distinguishing between different sub-types based on low-ionization potential species
> 3.0 km/s	<b>Detailed compositional analysis of </b> <u>icy</u> <b>particles</b> – identification of even minor components embedded in the ice matrix
5 – 15 km/s	<b>Detailed compositional analysis*</b> – full range of molecular fragments identified in impact ionization mass spectra
> 15 km/s	Elemental composition – easy to interpret, relevant to interstellar and interplanetary particle

<sup>\*</sup> For best science results it requires a comprehensive laboratory calibration campaign using analogue dust particles. Postberg, personal comm.